

Ancon



Fully compliant with The Building (Amendment) Regulations 2018:

Car

Com

The Government's ban on combustible materials in external walls, following a review of fire safety in high-rise residential buildings

Ancon[®] SSTS and STS Thermally Insulated Balcony Connectors

For Steel-to-Steel Applications



We are one team. We are Leviat.

Leviat is the new name of CRH's construction accessories companies worldwide.

Under the Leviat brand, we are uniting the expertise, skills and resources of Ancon and its sister companies to create a world leader in fixing, connecting and anchoring technology.

The products you know and trust will remain an integral part of Leviat's comprehensive brand and product portfolio. As Leviat, we can offer you an extended range of specialist products and services, greater technical expertise, a larger and more agile supply chain and better, faster innovation.

By bringing together CRH's construction accessories family as one global organisation, we are better equipped to meet the needs of our customers, and the demands of construction projects, of any scale, anywhere in the world.

This is an exciting change. Join us on our journey.

Read more about Leviat at Leviat.com



Our product brands include:



HELIFIX

Ancon








Imagine. Model. Make.

Leviat.com



Steel-to-Steel Balcony Connectors

Ancon SSTS and STS are compact thermal breaks, typically used for connecting steel balconies to structural steel frames but which are equally suitable for other steel-to-steel applications.

The connectors comprise tension and compression components within a single combined unit, wrapped in class A1 noncombustible mineral wool insulation. The fabricated compression component is manufactured from either 1.4301 (grade 304) stainless steel referenced SSTS or hot-dip galvanised S355 plain carbon steel referenced STS. Stainless steel offers the greater thermal efficiency and is essential for applications requiring enhanced corrosion protection such as coastal areas.

The fabricated elements are designed to EN 1993 (Eurocode 3) and UKCA and CE marked to BS EN 1090 Part 1. The system is available in three standard stud sizes to accommodate a wide range of loads. Manufactured to order, the vertical centres of the four A4 stainless steel fixing studs can be specified to suit the exact requirements of the application.

A thermal plate, with an independently verified European reaction-to fire classification of A2-s1,d0, is located at each steel interface.

Design resistances are provided on page 4.

System Benefits

- Comprises materials of class A1/A2 combustibility only, ideal for high-rise construction
- Proven through thermal modelling to reduce heat loss and eliminate condensation risk
- ✓ Thermal pad located at each steel interface
- Bracket fabrication UKCA and CE marked to BS EN 1090-1
- ✓ Variable fixing heights to suit application
- In the case of SSTS, fully stainless steel components offer the ultimate corrosion protection and thermal efficiency benefits


Material Combustibility

Following a review of fire safety, the Government has banned the use of combustible materials in the external walls of high-rise residential buildings in England. The Ancon SSTS and STS connectors are fully compliant with the material combustibility requirements of The Building (Amendment) Regulations 2018. All components are either European classification A1 or A2-s1,d0. Contact Leviat for further information.

Thermal Performance

Thermal modelling of a typical application showed a reduction in heat loss of almost 50% compared to a direct steel connection. It also illustrated a temperature factor within the limits detailed in BRE document IP1/06 for eliminating condensation risks in buildings of any type, even those with high humidity e.g. swimming pools (0.90).


Dimensions



Installation Guidance

The SSTS/STS Balcony Connector is supplied in a single unit with thermal plates attached to both inner and outer faces. These plates should not be removed. The assembly features all necessary steel fixings. Care should be taken to avoid damaging any balcony connector components prior to and during installation. It is essential that the connector is orientated and installed correctly.


Prior to installation of the connector, it is important to check the product dimensions against the engineer's drawings, specifically ensuring the mating parts match the connector stud centres.



The SSTS/STS Balcony Connector should be orientated so that the label indicating the uppermost face is correctly positioned and is facing out of the building.

Position the connector close to where it is to be installed. Ensure the connector is stable and not likely to fall. Carefully remove the nuts and washers from the studs on the inner face. Keep the steel nuts and steel washers close to hand. All non-metallic packing around the fixings should be discarded at this point, leaving the heat-shrunk isolation material on the stainless steel stud. Carefully lift and fit the exposed studs through the appropriate holes in the building structure. Do not force the connector into position. Re-fit the steel washers and steel nuts. Once the connector is fully aligned with the structure, torque up the nuts with a calibrated hydraulic torque wrench and suitable socket, referencing the table below.

Connector	SSTS/STS 16A	SSTS/STS 20A	SSTS/STS 24A
Wrench Size (A/F)	24	30	36
Torque (Nm)	148	288	498



Once all connectors are correctly positioned and fitted to the building structure, the balcony beams can be installed.

Remove the nuts and washers from the outer face of the connector and keep close to hand. Discard all non-metallic packing around the fixings to expose the heat-shrunk isolation on the stud.

Carefully lift the balcony fabrication, ensuring the balcony is horizontal. Align the balcony and carefully push over the exposed studs. Do not force it into position.

When positioned, re-fit the steel washers and steel nuts.

Once the balcony is fully aligned with the connector and structure, tighten the nuts to the correct torque. Remove all lifting straps.



Design Resistances

	STS 16A (Galvanised Steel)			SSTS 16A (Stainless Steel)			
Vertical Bolt Centres	Design Shear Resistance V _{Rd} (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	Design Shear Resistance V _{Rd} (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	
70mm		12.66			12.66		
75mm		13.57			13.57		
100mm		18.09			18.09		
125mm		22.61			22.61		
150mm		27.14			27.14		
175mm		31.66			31.66		
200mm	60.75	36.18	180.9	39.36	36.18	180.9	
225mm		40.70			40.70		
250mm		45.23			45.23		
275mm		49.75			49.75		
300mm		54.27			54.27		
325mm		58.79			58.79		
350mm		63.32			63.32		

	STS 20A (Galvanised Steel)			SSTS 20A (Stainless Steel)			
Vertical Bolt Centres	Design Shear Resistance V _{Rd} (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	Design Shear Resistance V _{Rd} (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	
70mm		19.75			13.87		
75mm		21.17			14.87		
100mm		28.22			19.82		
125mm]	35.28			24.78		
150mm]	42.33			29.73		
175mm]	49.39			34.69		
200mm	60.75	56.44	282.2	39.36	39.64	198.2	
225mm]	63.50			44.60		
250mm	1	70.55			49.55		
275mm	1	77.61			54.51		
300mm	1	84.66			59.46		
325mm	1	91.72			64.42		
350mm	1	98.77			69.37		

	STS 24A (Galvanised Steel)			SSTS 24A (Stainless Steel)			
Vertical Bolt Centres	Design Shear Resistance V _{Rd} (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	Design Shear Resistance V _⊮ (kN)	Design Resistance for Bending M _{Rd} (kNm)	Design Resistance for Tension N _{Rd} (kN)	
85mm		25.80	304	61.1	21.11	248.3	
100mm	-	30.35			24.83		
125mm		37.94			31.04		
150mm		45.53			37.25		
175mm		53.11			43.45		
200mm	78.1	60.70			49.66		
225mm	- /8.1	68.29			55.87		
250mm		75.88			62.08		
275mm		83.46			68.28		
300mm		91.05			74.49		
325mm		98.64			80.70		
350mm		106.23			86.91		

Design Example

Known requirements:

The Factored Ultimate Shear Force per connector, V_{E1} is 75kN. The Factored Ultimate Moment per connector, M_{E1}, is 45kNm. Vertical bolt centres are limited to a maximum of 150mm

From the tables:

- X STS16A at 150mm centres gives V_{Rd} = 60.75kN and M_{Rd} = 27.14kNm These connectors do not give the required capacity
- **X** STS20A at 150mm centres gives $V_{Rd} = 60.75$ kN and $M_{Rd} = 42.33$ kNm
- ✓ STS24A at 150mm centres gives V_{Rd} = 78.1kN and M_{Rd} = 45.53kNm. This connector meets the project requirements

Known requirements:

The Factored Ultimate Shear Force per connector, V_{Ea}, is 58kN The Factored Ultimate Moment per connector, M_{Ea}, is 35kNm Vertical bolt centres are limited to a maximum of 150mm

From the tables:

- **X** SSTS16A at 150mm centres gives V_{Rd} = 39.36kN and M_{Rd} = 27.14kNm
- X SSTS20A at 150mm centres gives V_{Rd} = 39.36kN and M_{Rd} = 29.73kNm The above connectors do not give the required capacity
- ✓ SSTS24A at 150mm centres gives V_{red} = 61.1kN and M_{red} = 37.25kNm This connector meets the project requirements

Leviat occasionally supply:

- · Special units with compression components top and bottom to accommodate uplift forces
- Special heavy duty units with multiple tension components and / or compression components

Ancon standard balcony connectors are designed to offer innovative solutions for a variety of load cases and construction geometries.

For arrangements not covered by the standard connectors, bespoke engineered solutions are available upon request. Please contact our technical team to discuss your requirements.

Worldwide contacts for Leviat:

Australia

Leviat 98 Kurrajong Avenue, Mount Druitt Sydney, NSW 2770 Tel: +61 - 2 8808 3100 Email: info.au@leviat.com

Austria

Leviat Leonard-Bernstein-Str. 10 Saturn Tower, 1220 Wien Tel: +43 - 1 - 259 6770 Email: info.at@leviat.com

Belgium

Leviat Industrielaan 2 1740 Ternat Tel: +32 - 2 - 582 29 45 Email: info.be@leviat.com

China Leviat

Room 601 Tower D, Vantone Centre No. A6 Chao Yang Men Wai Street Chaoyang District Beijing · P.R. China 100020 Tel: +86 - 10 5907 3200 Email: info.cn@leviat.com

Czech Republic Leviat Business Center Šafránkova Šafránkova 1238/1 155 00 Praha 5 Tel: +420 - 311 - 690 060 Email: info.cz@leviat.com

Finland Leviat Vädursgatan 5 412 50 Göteborg/Sweden Tel: +358 (0)10 6338781 Email: info.fi@leviat.com

France

Leviat 6, Rue de Cabanis FR 31240 L'Union Toulouse Tel: +33 - 5 - 34 25 54 82 Email: info.fr@leviat.com

<mark>Germany</mark> Leviat

Liebigstrasse 14 40764 Langenfeld Tel: +49 - 2173 - 970 - 0 Email: info.de@leviat.com

India

Leviat 309, 3rd Floor, Orion Business Park Ghodbunder Road, Kapurbawdi, Thane West, Thane, Maharashtra 400607 Tel: +91 - 22 2589 2032 Email: info.in@leviat.com

Italy

Leviat Via F.IIi Bronzetti 28 24124 Bergamo Tel: +39 - 035 - 0760711 Email: info.it@leviat.com

Malaysia

Leviat 28 Jalan Anggerik Mokara 31/59 Kota Kemuning, 40460 Shah Alam Selangor Tel: +603 - 5122 4182 Email: info.my@leviat.com

Netherlands Leviat Oostermaat 3 7623 CS Borne Tel: +31 - 74 - 267 14 49 Email: info.nl@leviat.com

New Zealand

Leviat 2/19 Nuttall Drive, Hillsborough, Christchurch 8022 Tel: +64 - 3 376 5205 Email: info.nz@leviat.com

Norway

Leviat Vestre Svanholmen 5 4313 Sandnes Tel: +47 - 51 82 34 00 Email: info.no@leviat.com

Philippines Leviat 2933 Regus, Joy Nostalg, ADB Avenue Ortigas Center Pasig City Tel: +63 - 2 7957 6381 Email: info.ph@leviat.com

Poland Leviat UI. Obornicka 287 60-691 Poznan Tel: +48 - 61 - 622 14 14 Email: info.pl@leviat.com

Singapore Leviat 14 Benoi Crescent Singapore 629977 Tel: +65 - 6266 6802 Email: info.sg@leviat.com

<mark>Spain</mark> Leviat

Polígono Industrial Santa Ana c/ Ignacio Zuloaga, 20 28522 Rivas-Vaciamadrid Tel: +34 - 91 632 18 40 Email: info.es@leviat.com

Sweden

Leviat Vädursgatan 5 412 50 Göteborg Tel: +46 - 31 - 98 58 00 Email: info.se@leviat.com

Switzerland Leviat Grenzstrasse 24 3250 Lyss Tel: +41 - 31 750 3030 Email: info.ch@leviat.com

United Kingdom Leviat President Way, President Park, Sheffield, S4 7UR Tel: +44 - 114 275 5224 Email: info.uk@leviat.com

United States of America Leviat 6467 S Falkenburg Rd. Riverview, FL 33578 Tel: (800) 423-9140 Email: info.us@leviat.us

For countries not listed Email: info@leviat.com

Notes regarding this catalogue

Leviat.com

© Protected by copyright. The construction applications and details provided in this publication are indicative only. In every case, project working details should be entrusted to appropriately qualified and experienced persons. Whilst every care has been exercised in the preparation of this publication to ensure that any advice, recommendations or information is accurate, no liability or responsibility of any kind is accepted by Leviat for inaccuracies or printing errors. Technical and design changes are reserved. With a policy of continuous product development, Leviat reserves the right to modify product design and specification at any time.



For more information on these products, contact:

Leviat President Way President Park Sheffield, S4 7UR United Kingdom

Tel: +44 (0) 114 275 5224 Fax: +44 (0) 114 276 8543

Email: info.ancon.uk@leviat.com

For sales and technical enquiries: Email: reinforcement.uk@leviat.com

Ancon.co.uk Leviat.com

Imagine. Model. Make.

Leviat.com